




USE AND CARE GUIDE

USA Item 1015092967
Mexico Item 240794
Model 26SV25555

12 FT Grave & Bones Giant-Sized Animated LED App
Controlled Skelly with LifeEyes LCD Eyes



To get started, Please hold the
“MODE” button for 7 seconds to
take the item out of demo mode.

Note: There may be slight differences between the App and Instruction manual. Please refer to the App for the actual interface. Please download the latest version of the app.

Please scan QR
code to download
APP. Please refer to
the App instruction
manual for details.

ASSEMBLY REQUIRES AT LEAST 2 ADULTS, 3 ADULTS ARE RECOMMENDED.
PLEASE FOLLOW THE STEP BY STEP GUIDE AND ENJOY YOUR 12 FT GRAVE
& BONES GIANT-SIZED ANIMATED LED APP CONTROLLED SKELLY WITH
LIFEYES LCD EYES!


Questions, problems, missing parts? Before returning to the store, Please have a copy of your receipt
ready and email the SVI customer experience team (customerservice@svius.com) within 90 days of
the date of purchase or call Home Accents Holiday Customer Service 8 a.m. - 7 p.m., EST,
Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-855-HD-HOLIDAY (1-855-434-6543)
HOMEDEPOT.COM

PARTS LIST

- A. Base x 1
- B. Right Foot x 1
- C. Left Foot x 1
- D. Right Lower Support Pole x 1
- E. Left Lower Support Pole x 1
- F. Right Shin x 1
- G. Left Shin x 1
- H. Upper Support Poles x 2
- I. Right Femur x 1
- J. Left Femur x 1
- K. Pelvis x 1
- L. Spinal Support x 1
- M. Ribcage x 1
- N. Right Humerus x 1
- O. Left Humerus x 1
- P. Right Forearm x 1
- Q. Left Forearm x 1
- R. Head x 1
- S. Base Stabilizers x 4
- T. Loop Screw x 1
- U. Tether Cable x 1
- V. Stakes x 4
- W. Adapter * x 1
- X. Small Parts Bag x 1



Power Adapter * Spec
Input: 120V~60Hz
Output: 5.9V --- 3.0A
Wattage: 17.7W




TOOLS REQUIRED



NOTE: Throughout the instructions, Right
and Left are relative to the character.
Hex wrench included for assembly.




1.1




1.2

NOTE: Slide the two shins over
the lower support poles and fit
them onto the feet as shown.




2.1




2.2



NOTE: Slide the two femurs onto the upper support poles and then fit them onto the shins as shown.




NOTE: A ladder and more than 2 people are advised when assembling the (K) Pelvis to the (H) Upper Support Poles and the (I, J) Femurs. If there is difficulty in assembling the (K) Pelvis, try adjusting the upper legs until they are properly aligned.



NOTE: Lean the skeleton against the box it came with for easier assembly. 3 adults are strongly recommended for this step.





After connecting the wires, hide the excess inside the available cavity at the bottom of the (M) Ribcage.



NOTE: Screw the loop into the area inside of the spine as shown.



NOTE: Do not overtighten this screw. Overtightening may result in damage to the product. The hex screw should be perpendicular to the grooves on the shoulder. If a screw is missing, check inside the box as it may have fallen out of the arm.




NOTE: The 12 FT Grave & Bones Giant-Sized Animated LED App Controlled Skelly with LifeEyes LCD Eyes has 4 different function settings (BLUETOOTH, LIGHTS ONLY, OFF-STEP PAD and TIMER-SENSOR) and 20 different Eye Options (MODES) to choose from from - see images on box.

Settings can be controlled at the Control Panel but eyes can only be toggled with the DECOR PRO phone App.
Timer setting is only available on the Skeleton Control Panel, located on the underside of the Pelvis (K).

OPERATION INSTRUCTIONS - CONTROL BOX:

Plug the power adapter into a standard power outlet. Locate the push button on the control panel underneath the Pelvis (K). This button lets the user toggle between BLUETOOTH, LIGHTS ONLY, OFF/STEP PAD, and TIMER/SENSOR.



2. Settings:

	Press the MODE button to switch to "Bluetooth" Mode. Please refer to the APP Operation Instructions.
LIGHTS ONLY / ÉCLAIRAGE UNIQUEMENT / SÓLO LUCES	This switch mode will activate only the LifeEyes LCD eyes and lights of the item indefinitely until the switch mode is changed from the lights only setting.
OFF • STEP PAD / ARRÊT • TAPIS ÉLECTRONIQUE / APAGAR • ALMOHADILLA DE PASO	This switch mode allows the item to be activated only if triggered by using a Step Pad or Try Me Button (Not Included). The lights, sounds, and animation of the item will operate for one activity cycle with each Step Pad or Try Me activation. Otherwise, the item will stay off.
TIMER • SENSOR / MINUTEUR • DÉTECTEUR / TEMPORIZADOR • SENSOR	This switch mode will activate SENSOR mode for 6 hours followed by a deactivated period of 18 hours. This cycle will continue indefinitely unless the setting is changed. During the 6-hour active period, the Infra-red (IR) sensor can be triggered. If the Infra-red (IR) sensor is activated, the prop will activate for one activity cycle (animation and sound). The infra-red (IR) sensor has a range of up to 4 m/13 ft and will activate when someone comes within an 80-degree angle from left to right as well as from above or below.
SPEAKER/ HAUT-PARLEUR / BOCINA	Plug any external speaker into this receiver using a 3.5 mm audio jack.
	Raise or lower the volume using the volume control turn dial, turn all the way down to turn the volume off .

THIS PRODUCT IS COMPATIBLE WITH EXTERNAL TIMERS AND PRESERVES ITS SETTING WHEN THE POWER IS TURNED OFF/ON.

WARNING

This item is not a toy and should be used for decoration only. This item contains small parts that can be a choking hazard. Keep all plastic and wire parts away from children.

- 1. Please use the adapter supplied by manufacturer.
- 2. Please assemble item according to instructions. Connect all wires according to matching color.
- 3. Children should be supervised by adults. Item should not be grabbed, as it becomes a tipping hazard. Keep flammables away from the adapter, as it heats up during operation.

Please view all instructions carefully before assembling. Save this instruction sheet for future reference.

- ☐ Lay product down before a storm or strong winds.
- ☐ Don't climb or pull on product.
- ☐ Do not add to or modify unless accessory is designed for product
- ☐ Assemble and place the product on level surfaces only.
- ☐ Don't push or tilt product.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ☐ Reorient or relocate the receiving antenna.
- ☐ Increase the separation between the equipment and receiver.
- ☐ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ☐ Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s).Operation is subject to the following two conditions:
1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

CAN ICES (B) / NMB (B)

1


WE SUGGEST AT LEAST TWO ADULTS FOR ASSEMBLY

2

NO MOVING AFTER FULLY ASSEMBLED

3

LEVEL AREA ONLY

7

USE WEIGHTS ON THE BASE

8

USE INCLUDED ADAPTER ONLY

9

CAUTION
DAMAGE COULD OCCUR IN HIGH WINDS

4


DO NOT PUSH OR TILT

5

DO NOT CLIMB OR PULL ON

6

DO NOT ADD TO OR MODIFY

10

CONTACT US
IF MOVEMENT, SOUND OR LIGHTS DON'T WORK

11

CONTACT US
1-855-434-6543
(1-855-HDHoliday)

Troubleshooting

Problem	Solution
The prop has no sound, movement, or lights in the eyes or chest.	Ensure that all cables are firmly connected to their corresponding cables. Make sure that the adapter is plugged into a live outlet and that the adapter is plugged firmly into the adapter receiver. If the issue persists, contact customer service.
Is sound on your 12ft App Skelly not working?	Please make sure that nothing is plugged into the speaker jack unless you are using an external speaker.
Is the try me port not working?	Please make sure your try-me button is not plugged into the speaker jack.

FAQ:

Why are the eyes of my 12 FT Grave & Bones Giant-Sized Animated LED App Controlled Skelly with LifeEyes LCD Eyes not working or do not light up?

- Check and ensure that all cables are connected to their corresponding cable as shown in the instruction sheet (See steps 5.1 and 7.2)

My item does not activate or turn ON?

- Check that the adapter is properly connected with the threaded cap fully tightened to your 12ft Giant Skelly and is plugged into a live outlet. (See step 8.1)
- Check and ensure that there is power to your 12 FT Grave & Bones Giant-Sized Animated LED App Controlled Skelly with LifeEyes LCD Eyes by checking for the red indicator light on the control panel. If there is power, a red indicator light will light up on the control box. If the red light indicator is set to "OFF", please change it to "BLUETOOTH," "LIGHTS ONLY," or "TIMER-SENSOR."

If all the information above does not solve your issue, please contact our SVI customer service experience team email (customerservice@svius.com) or call Home Accents Holiday Customer Service Hotline 1-855-HD-HOLIDAY (1-855-434-6543)

Questions, problems, missing parts? Before returning to the store, Please have a copy of your receipt ready and email the SVI customer experience team (customerservice@svius.com) within 90 days of the date of purchase or call Home Accents Holiday Customer Service 8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-855-HD-HOLIDAY (1-855-434-6543)
HOMEDEPOT.COM

5/5